

## **TASKI ULTIMAXX 360 User Guide**

## **Preparation**



Lean machine back. Line up and fit clean brushes or pad holders with clean pads.



**Operation** 

Fit waste water tank. Line up and push.



Insert the battery with handle pointing towards you.



Remove the solution tank (orange) from the machine by pulling on the handle.



Fill solution tank horizontally with clean water. Dose cleaning product into solution tank



Refit solution tank into machine. Slide tank along handle bar.



Switch machine on, pressing power button The battery indicator will light up.



Pull side lever.



Pull machine towards you. The squeegee unit and recovery tank will automatically position in working position.



Press the orange lever to start.



Set the working conditions. Vacuum motor (on/off), Water setting (+/-), Twister Button (on/off), Eco Mode (on/off).



Use
ErgoHandle
to turn and
manoeuvre
the machine.



Press the orange parking button to lock the handle in the upright position.



To park, pull the machine towards you. The squeegee unit and recovery tank will lift off.



Press yellow button and pull to remove the recovery tank.



Remove the solution tank from the machine.



Open the solution tank lid. Empty and rinse. Replace tank on to machine.



Open the top hole of the recovery tank. Empty the tank.



Open the recovery tank through the side locks. Rinse.



Remove filter by twisting and rinse. Re-insert the filter.



Re-close the recovery tank and replace on to machine.



Press release lock and pull out the battery.



Put the battery on charge.



back and remove brushes/pad holders/pads by pulling. Clean and rinse. Replace pads as needed.

Push machine



To replace squeegee blades, first open the recovery tank and then remove the yellow screws.



Remove squeegee assembly and then remove blades. Line up and insert new blades.



Attach squeegee unit, re-insert yellow screws and close the tank.





Don't pull the machine without the recovery tank in place.



Be aware of side-lock angle.



Properly insert the solution tank.



Do not carry the machine by the battery handle or the recovery tank.

## **ATTENTION!**

Do not use the machine before you have read and understood the operating instructions! Questions: 1-800-558-2332