Ultimaxx 1900

Preparation



Unplug machine when batteries are fully charged



Open lid of machine



Fill tank with water



Dose chemicals manually



or with using IntelliDose +



Place the brush / padholders



Connect the hose to the squegee



Start machine by pushing the key



Lower brush units by using the manual lever (by foot)



Or automatically



And lower the squeegee2



Start water, vacuum motor and choose water level



Use paddles to start cleaning



Lift brush unit



Lift squeegee



Empty the tank



Remove squeegee and rinse with water



Check filter and rinse with water



Remove brush and clean it



Remove filter



Empty filter and rinse with water



Check filter and rinse with water



Store machine with open lid



Plug machine in if needed

ATTENTION!

Do not use the machine before you have read and understood the operating instructions! **Questions: 1-800-558-2332**